



Made in Germany!
Importer: Ltd "Abschliff Latvija"
Riga, A Čaka iela 107 K2
Phone: +371 67843844, 67843845
Fakss: +371 67272792
Mob.: +371 26177888
E-mail: abschliff.latvija@gmail.com
Facebook/Abschliff Abschliff



Open: Monday to Friday – 9⁰⁰-18⁰⁰, Saturday- 10⁰⁰-14⁰⁰, Sunday – closed

BergerBond Primer P

Description: 1-component primer on the basis of high-quality polyurethane raw materials. Free of water and solvents! Specially recommended for priming under BergerBond P1, BergerBond P2/P2S, BergerBond M1P/M1/M1S/M1X and BergerBond K1. Suited for absorbing and non-absorbing subfloors. Giscode: RU1 Emicode: EC1

Technical data.

Mixing ratio: not applicable 1-2 h

Fit for further work on after: 1-2 h

Flash-off time: no

Suitable for in-floor heating: yes.

Special notes: do not use Berger Bond Primer P in conditions below + 15°C or above 65% rel. humidity. In the cold season adhesive and flooring elements should be given time to reach the same temperature.

Application: Thoroughly shake BergerBond Primer P before using. When applying the primer with the foam roller (BergerTool Schaumstoffrolle) or with the brush, take care to spread it evenly. Don't allow puddles to build up.

If you don't give the BergerBond Primer P time enough to dry, when applying the hardwood floor adhesive, bubbles will occur. In this case the adhesion is failing.

When BergerBond Primer P is used as moisture barrier, it must be applied in 3 layers. The individual layers are applied crosswise. Each layer must be dry and must have got a closed film to make a perfect bond under putties and adhesives; only after that work can continue.

The last layer is to be sprinkled with sand when still wet so that to get an optimum connection with the surfaces or adhesives to be applied upon it. When using the product under PUR or silane adhesives, you can do without sanding within a period of 48 hours.

Consumption. When used as primer: approx. 150 g/m². When used as moisture barrier: approx. 400 g/m², depending on the absorbing capacity of the substrate.

Subfloor: the subfloor must be clean (free of contaminations), dry (permanently dry), firm, plane and free of cracks. The requirements of DIN 18356 "Wood flooring works" must be met.

The primer's use as moisture barrier against capillary rising moisture is an exception.

If the adhesives BergerBond P1, BergerBond P2/P2S, BergerBond M1P/M1/M1S/M1X and BergerBond K1 are used upon in-floor heating, it has to be checked if the subfloor needs to be primed with BergerBond Primer P. The primer must dry sufficiently.

In case BergerBond Primer P is applied upon anhydrite or anhydrite flowing screeds, the subfloor must be mechanically pre-treated according to the valid standards or the manufacturers' instructions.

Storage/transport: can be stored for at least 9 months as from the date of production if transported and stored in cool and dry conditions, and if the original packaging is not opened. Protect from frost!

Packaging: 6 kg/ 11kg.

